

Terresolve Flushing Procedure



1. Run equipment until normal operating temperature is reached. Drain petroleum hydraulic fluid and retain a 4 ounce sample labeled accordingly.
2. Fill system with EnviroLogic® BioFlush. Run equipment for 5 minutes or through each hydraulic cycle until fluid is completely circulated through the system.
3. Drain EnviroLogic® Bioflush mixture and retain a 4 ounce sample labeled accordingly.
4. Fill system with recommended and approved Terresolve EnviroLogic® Product. Run equipment for 5 minutes and collect and label a 4 oz. sample.
5. Please send all samples to Terresolve for evaluation as a baseline for monitored oil analysis of the unit.

The hydraulic system is now optimized for fluid biodegradability in the event of leakage!